



L.C. s.r.l.

Via I° Maggio 59

25010 ISORELLA – BS – ITALY

Tel. +39 030 9529040 Fax +39 030 9529638



info@lcpese.it


www.lcpese.it

X-TYPE EASY



User's manual





CHARACTERISTICS

| | |
|---------------------|--------------------------------|
| FS Range | 0-99.999 |
| Divisions | 1-2-5-10-20-50 |
| Precision | < +/-0,015 % F.S. |
| Linearity | 0,0012 % F.S. |
| Working temperature | -10 / +50 °C |
| Max humidity | 85 % |
| LED Display | 38mm, 7 segments, Red |
| Keyboard | Mechanic |
| Power Supply | 9-36 VDC |
| Box | Aluminum |
| Connectors | Military type : 2 – 5 – 7 Pins |
| Dimensions | 23 X 18 X h7 cm |
| Weight | 2.500 gr |
| | |
| | |
| | |
| | |
| | |


Index:

TURNING ON

USE

PARAMETERS


TURNING ON



TURNING ON AND ZEROING THE TARE :

PRESS THE RED KEY  AND WAIT FOR THE DATA LOADING.

THE DEVICE WILL SHOW THE TOTAL WEIGHT.

PRESS THE KEY  FOR 10 SECONDS AND RELEASE IT WHEN THE DISPLAY SHOWS 0.

MANUAL USE

LOAD INTO THE MACHINE THE FIRST PRODUCTS EX. 350Kg.

THE SCALE SHOWS THE TOTAL WEIGHT **TOT 350**

PRESS THE KEY 

THE SCALE SHOWS THE PARTIAL WEIGHT **P 0**





LOAD INTO THE MACHINE THE SECOND PRODUCT Ex. 200Kg.

THE SCALE SHOWS THE LAST LOADED PARTIAL WEIGHT

PRESS THE KEY **TOT PAR**

THE SCALE SHOWS THE TOTAL WEIGHT **TOT 550**

THE TOTAL IS THE WEIGHT IN THE MACHINE.

PRESS THE KEY **TOT PAR** THE SCALE SHOWS **P 0**



LOAD THE THIRD COMPONENT Ex. 600Kg

THE SCALE SHOWS THE LAST LOADED PARTIAL WEIGHT

PRESS THE KEY **TOT PAR**

THE SCALE SHOWS THE TOTAL WEIGHT **TOT 1150**

(THE SUM OF THE THREE PRODUCTS LOADED INTO THE MIXER FEEDER WAGON.)



DURING THE SHIFTS IT IS POSSIBLE TO LOCKE THE WEIGHT, BY PRESSING THE KEY **BLOK SBLOCK**







PARAMETERS



PRESS THE KEY  FOR ABOUT 15 SECONDS, WHEN YOU ARE IN THE TOTAL WEIGHT MODE.





DIV. (READING DIVISION) WILL APPEAR. CONFIRM WITH THE KEY  AND WITH THE KEYS   SELECT THE REQUIRED VALUE. THE SETTABLE VALUES ARE 1-2-5-10-20-50 kg. CONFIRM WITH THE KEY  TO SAVE THE VALUE.



PRESS THE KEY  AND SPEED APPEARS. CONFIRM WITH THE KEY  AND WITH THE KEYS   SELECT THE REQUIRED VALUE.



THE SETTABLE VALUES GO FROM 1 TO 6 (1 FAST AND 6 SLOW), CONFIRM WITH THE KEY , PRESS THE KEY  TO RETURN TO THE TOTAL.



STATEMENT OF CONFORMITY:

THE FIRM

L.C. s.r.l.

Via I Maggio, 59

25010 Isorella - BS -

DECLARES THAT:

WEIGHING MACHINE Mod. X-TYPE EASY
CONFORMS TO THE REGULATIONS SPECIFIED
IN DIRECTIVE **EMC 89 / 336 93 / 68.**

WARRANTY

THE FIRM **L.C. s.r.l.** GUARANTEES ITS PRODUCTS FOR 24 MONTHS FROM THE DATE OF PURCHASE. THE GUARANTEE COVERS THE REPLACEMENT OR REPAIR WITHOUT CHARGE, AT OUR FACTORY, OF ANY PARTS THAT ARE FOUND TO BE DEFECTIVE AS A RESULT OF THE MANUFACTURING PROCESS. THE WARRANTY DOES NOT COVER ANY PARTS THAT MAY BECOME DEFECTIVE THROUGH NEGLIGENCE OR LACK OF CARE IN USAGE, THROUGH INCORRECT INSTALLATION OR MAINTENANCE CARRIED OUT BY UNAUTHORISED PERSONNEL, DAMAGE IN TRANSPORTATION, OR DUE TO ANY CIRCUMSTANCES THAT ARE NOT DIRECTLY RELATED TO FAULTS IN THE MANUFACTURING PROCESS OF THE DEVICE. THE MANUFACTURER DECLINES ANY RESPONSIBILITY FOR ANY DAMAGE THAT MAY OCCUR, EITHER DIRECTLY OR INDIRECTLY, TO PEOPLE, ANIMALS OR OBJECTS AS A CONSEQUENCE OF INCORRECT ADHERENCE TO THE INDICATIONS REPORTED IN THIS BOOKLET.